



NOTES:

1. PLACE 3/4 INCH EXPANSION JOINTS AT LOCATIONS SHOWN OR AS DIRECTED BY THE ENGINEER.
2. FORM CONTROL JOINTS 1/4 INCH WIDE AND 3/4 INCH DEEP AT A MAXIMUM SPACING OF 10'.
3. IF THE NEAREST EXISTING EXPANSION JOINT IS 5 FEET OR LESS FROM THE DRIVEWAY RADIUS, THEN REMOVE AND REPLACE CURB AND GUTTER TO THE NEAREST EXPANSION JOINT.

SCALE: NTS

**RECORD SIGNED COPY
ON FILE**

APPROVED

01-28-21

DATE

**THE ARCHITECT/ENGINEER ASSUMES
RESPONSIBILITY FOR THE APPROPRIATE
USE OF THIS DETAIL.**

CITY OF ROUND ROCK

**CONCRETE DRIVEWAY DETAIL
TYPE I RESIDENTIAL**

**DRAWING NO:
ST-02
SHEET 1 of 1**

