

Setting RUN TIMES on a Hunter Pro-C, ICC, or X-Core Irrigation Controller

1. Turn dial to SET STATION RUN TIMES
 - Display will show “Station 1” and 0:00. This is station 1 and how many hours or minutes it will run.
2. Push + button to add time. The numbers shown are minutes being added. Continue to push + until you get to the length of time you want the station to run.
3. Move to Station 2 by pushing the right arrow (→).
 - Push + button to add time. The numbers shown are minutes being added.
4. Continue repeating these steps until all stations have minutes added on.
5. Turn dial back to RUN. This will allow the controller to start running the schedule you’ve set. You can also turn the dial to SYSTEM OFF to keep the irrigation turned off until you want it to run. Having it on OFF does not erase what you’ve just programmed.

