

Setting Your Rain Bird ESP SERIES or ESP Modular Irrigation Controller

1. Turn dial to SET VALVE RUN TIMES and #1.
 - Display will show “Valve 1” and :00 minutes. This is station 1 and how many minutes it will run.
2. Push **↑/ON** button to add time or **↓/OFF** to decrease the time. The numbers shown are minutes being added or subtracted.
3. Move to Station 2 by turning the dial to 2.
 - Push **↑** or **↓** to add or subtract time.
4. Continue repeating these steps until all desired stations have a runtime.
5. Turn dial back to AUTO. This will enable the controller to start running the schedule. You can also turn the dial to OFF to keep the irrigation turned off. Having it OFF does not erase what you’ve just programmed in.

